4

Move

- 0.1mm | 1mm | 10mm
- Z+
- Y | X+
- X- | Y+
- Z-
- Move | Temperature | Extruder

NEPTUNE 4 PLUS

- Print
- Prepare
- Settings
- Level

- X 100.0
- Y 100.0
- Z 100.0
- 200 / 200
- 60 / 60

Settings

- Language — English >
- WLAN — emily456 >
- Lighting Control >
- Fan
- Move-off
- Filament Detector
- Factory Default Settings
- About Machine >
- Advanced Settings >

Level

- 145°C/145°C 60°C/60°C
- 0.01mm | 0.1mm | 1mm
- Z-offset
- ▲ mm ▼
- Auxiliary leveling | Automatic leveling

Print

Model1.gcode

ELEGOO

Settings

resume

Stop

Led

| 25 % | 17 h 24 min |

X[???] Y[115]

17 h 24 min	0.28
200 / 200	60 / 60
100 %	100 %
0.023 mm/s	100 %

A   B   C

Print screen:
- Model1.gcode
- ELEGOO
- Settings
- resume
- Stop
- 25% 17 h 24 min
- X[???] Y[115]
- Led
- 17 h 24 min
- 0.28
- 200/200
- 60/60
- 100%
- 100%
- 0.023 mm/s
- 100%

Adjust screen:
- 0.01mm 0.1mm 1mm
- Z-offset
- mm
- Filament detector
- Speed adaptive mode
- LED
- 192.168.3.164
- Filament
- Speed
- Adjust

Ultimaker Account

Your key to connected 3D printing

- Customize your experience with more print profiles and plugins
- Stay flexible by syncing your setup and loading it anywhere
- Increase efficiency with a remote workflow on Ultimaker printers

Sign in

Create account

Skip

Add a printer

Add a networked printer

There is no printer found over your network

Refresh   Add printer by IP   Add cloud printing troubleshooting

Add a non-networked printer

Next